

USER GUIDE & INSTALLATION INSTRUCTIONS

DESCRIPTION: King Tour Pad
FITMENT: Harley-Davidson® Touring models 2014-2023

PART NUMBER: 814-07-TPACK

CONTENTS / PARTS INCLUDED:

Qty	Item	Qty	Item	Qty	Item
1	King Tour Pad	3	Washers	3	Hex Cap Nuts

OVERVIEW:

This Saddlemen® King Tour Pad is designed as a direct replacement for the Harley-Davidson® Tour Pak® backrest pad on your 2014 or later Harley Davidson Touring model. It's the easiest way to match your backrest to your Saddlemen seat, completing the look of your bike.

IMPORTANT:

Please read these instructions completely before starting installation. All "NOTE," "CAUTION" and "WARNING" notations are serious safety issues and should be read carefully. Possible injury to riders or damage to the motorcycle and/or accessory may result if improperly installed.

NOTICE TO DEALERS:

These instructions contain important information for future reference and should be given to the customer.

⚠ WARNING:

READ THESE INSTRUCTIONS THOROUGHLY BEFORE INSTALLATION!

Because of the variety of motorcycle configurations, other accessories, and the intended use of this Saddlemen accessory, there could be many different mounting options. You are responsible for the proper installation of this accessory on your motorcycle. Your attention to these installation instructions and recommendations will permit safe and proper use of this backrest pad. You must mount this accessory properly and securely before riding your motorcycle. If you lack the ability to safely and properly install this accessory, seek out a qualified motorcycle technician for assistance. During installation, support the motorcycle with a suitable stand or lift so it will not tip over and injure you, or damage the vehicle. Using or mounting this accessory improperly could result in a loss of control of the motorcycle which could result in damage to your motorcycle or other personal property, the property of third parties, and/or personal injury to yourself or others, up to and including death.

BE SURE TO THOROUGHLY READ AND CLOSELY FOLLOW THE MOUNTING INSTRUCTIONS THAT ARE INCLUDED WITH THIS ACCESSORY:

- This backrest pad must be installed and securely fastened onto the Tour Pak® or similar foundation on the motorcycle.
- Install the backrest pad securely so it will not shift or move while riding. Make sure the mounting hardware will not contact the wheels, suspension or any other moving parts of the motorcycle.
- If you do not understand the mounting instructions DO NOT mount this backrest pad. Remove the base or any components you may have already installed on your motorcycle.
- Thoroughly inspect your motorcycle accessories before every ride. Do not use this backrest pad if the mounting system has been modified, has deteriorated, loosened or is beginning to fail.
- Continually check the security of the backrest pad at each stop as you ride. Hardware can loosen during operation, so be sure to check it frequently.
- Do not use this accessory if you have any doubts as to whether it is properly mounted to your motorcycle.
- If your backrest pad is ever damaged, do not use it until it's been inspected by your local professional motorcycle dealer. Remove it immediately if it has damage that prevents it from being properly secured to your motorcycle.

DO NOT ATTEMPT TO USE THIS ACCESSORY IF...

- You do not understand the installation and use of its instructions;
- You do not understand any part of the accessory mounting system;
- You have any doubts as to the security of the mounting system.

If you have any concerns or questions, seek help at your qualified motorcycle dealer or call the Saddlemen support line at (310) 638-1222.

 California Proposition 65 Warning

WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information: www.P65/Warnings.ca.gov

Remember: Motorcycling can be a dangerous activity. Installation of any accessory can increase your risk if it is not installed properly. You are responsible to install this accessory so it will not contact any portion of the drive train, suspension or steering, and so it will in no way interfere with the operation of your motorcycle.

IS-11-400452 TPACK Rev 2 (03-2025)

CAUTION:

To avoid injury, install while engine is cold.

For additional paint protection, use a Saddlemen Protective Tape Kit (PN: 4320-0807) which protects paint from abrasion damage from a seat, backrest pad or other accessory that may contact your paint. NOTE: It is not considered abnormal for your new Saddlemen product to touch the motorcycle's chassis in certain places. Due to the natural variance of your vehicle and your new Saddlemen pad, you should always check to see if portions of the pad are touching painted or finished surfaces on your motorcycle. If the test fitting of your pad indicates an area where it is touching a sensitive surface, you can protect that area by using the Saddlemen Protective Tape Kit.

INSTALLATION:



1. Open your motorcycle's Tour Pak.
2. Locate the three nuts that hold on the stock backrest pad. Remove them. Slide off the stock backrest pad.
3. Replace the backrest pad with your new Saddlemen King Tour Pad. The three studded mounting points are hinged, which will allow you to push the pad gently, but comfortably into place for a perfect fit.
4. When you've positioned the backrest pad correctly, install the three hex cap nuts and tighten. 100 to 120 in-lbs is the correct torque number.

IMPORTANT:

After 50 miles (80 kilometers), recheck all of the mounting hardware and the backrest pad to make sure it is still tight and secure. A loose backrest pad or hardware can interfere with the vehicle's operation and can cause an unsafe riding condition. After that, check fastener tightness during your regular maintenance checks.

LIMITED WARRANTY POLICY

SADDLEMEN LIMITED ONE-YEAR WARRANTY Saddlemen warrants its products for defects in materials, design or workmanship for a period of one year after retail purchase. Items that are defective will be repaired or replaced by Saddlemen at its sole discretion. Damage caused by improper use or improper installation is not a defect; therefore repair, replacement or shipping of a damaged accessory will not be covered under this warranty. This limited warranty contains other provisions and conditions, so please refer to the Warranty Policy that was provided with your backrest pad, or visit www.saddlemen.com for additional information. You can count on Saddlemen's quality, innovation, service and style. If for any reason you are not satisfied with the performance of your Saddlemen product, please contact the Saddlemen support line at (310) 638-1222.

IS-11-400452 TPACK Rev 1 (03-2025)